## CULTIVATION SYSTEM DEVELOPMENT PH.4 COURSE

2 APPENDIX

First edition



## TABLE OF CONTENTS

# Set up the I2C interfaceInstall the I2C library for the Python

# 1. SET UP THE I2C INTERFACE

I2C interface activation procedure





#### Type "sudo raspi-config" and press Enter.



Raspberry Pi Software C	onfiguration Tool (raspi-config)
1 Change User Password 2 Network Options 3 Boot Options 4 Localisation Options 5 Interfacing Options 6 Overclock 7 Advanced Options 8 Update 9 About raspi-config	Change password for the current u Configure network settings Configure options for start-up Set up language and regional sett Configure connections to peripher Configure overclocking for your P Configure advanced settings Update this tool to the latest ve Information about this configurat
<select></select>	<finish></finish>
Raspberry Pi 3 Model B Plus Rev 1.3	
Raspberry Pi Software Co	onfiguration Tool (raspi-config)
1 Change User Password 2 Network Options 3 Boot Options 4 Localisation Options 5 Interfacing Options 6 Overclock 7 Advanced Options 8 Update 9 About raspi-config	Change password for the current u Configure network settings Configure options for start-up Set up language and regional sett Configure connections to peripher Configure overclocking for your P Configure advanced settings Update this tool to the latest ve Information about this configurat
<select></select>	<finish></finish>

#### Select 5 Interfacing Options

Raspberry	/ Pi Software	Configuration Tool	(raspi-config)
P1 Camera P2 SSH P3 VNC P4 SPI P5 I2C P6 Serial P7 1-Wire P8 Remote GPIO		Enable/Disable Enable/Disable Enable/Disable Enable/Disable Enable/Disable Enable/Disable Enable/Disable	connection to the remote command lin graphical remote a automatic loading automatic loading shell and kernel m one-wire interface remote access to G
	<select></select>	<	Back>
P1 Camera P2 SSH P3 VNC P4 SPI P5 I2C P6 Serial P7 1-Wire P8 Remote GPI0	/ Pi Software	Configuration Tool Enable/Disable Enable/Disable Enable/Disable Enable/Disable Enable/Disable Enable/Disable Enable/Disable	<pre>(raspi-config) connection to the remote command lin graphical remote a automatic loading automatic loading shell and kernel m one-wire interface remote access to G</pre>
	<select></select>	<	Back>

Select P5 I2C



#### Select <Yes>

Select <Ok>

無断複製、転載を禁ずる。

©2021 Neo Career Promote CO.,LTD. All Rights Reserved.

Raspberry Pi	. Software Con	figuration Tool (raspi-config)
2 Network Options 3 Boot Options 4 Localisation Options 5 Interfacing Option 6 Overclock 7 Advanced Options 8 Update 9 About raspi-confi	.ons ons .g	Configure network settings Configure options for start-up Set up language and regional sett Configure connections to peripher Configure overclocking for your P Configure advanced settings Update this tool to the latest ve Information about this configurat
<5	elect>	<finish></finish>
<s aspberry Pi 3 Model B F</s 	Select>	<finish></finish>
<s aspberry Pi 3 Model B F Raspberry Pi</s 	Plus Rev 1.3 . Software Cont	<finish></finish>
Aspberry Pi 3 Model B F Raspberry Pi 1 Change User Passw 2 Network Options 3 Boot Options 4 Localisation Opti 5 Interfacing Optic 6 Overclock 7 Advanced Options 8 Update 9 About raspi-confi	Plus Rev 1.3 Plus Rev 1.3 Software Cont Ford Sons	<pre><finish> figuration Tool (raspi-config) Change password for the current u Configure network settings Configure options for start-up Set up language and regional sett Configure connections to peripher Configure overclocking for your P Configure advanced settings Update this tool to the latest ve Information about this configurat</finish></pre>

Select <Finish> with the TAB.

#### Type "sudo reboot" and press Enter.

pi@raspberrypi:~ \$ pi@raspberrypi:~ \$ sudo raspi-config pi@raspberrypi:~ \$ pi@raspberrypi:~ \$ sudo reboot

### Setting completed.

## 2. INSTALL THE I2C LIBRARY FOR THE PYTHON

Library Installation procedure



File Edit Tabs Help

pi@raspberrypi:~ \$ sudo apt update

Update system package list Type "sudo apt update" and press Enter.

File Edit	Tabs Help	
pi@raspber	r <b>ypi:∼ \$</b> sudo apt up	pgrade

Upgrade all installed packages to the latest version Type "sudo apt upgrade" and press Enter.

File	Edit	Tabs	Help						
pi@ras	pber	rypi:∼	\$ sud	o apt	clean				

Clear package cache Type "sudo apt clean" and press Enter. File Edit Tabs Help

pi@raspberrypi:~ \$ sudo apt install python3-smbus

Type "sudo apt install python3-smbus" and press Enter.

File Edit Tabs Help pi@raspberrypi:~ \$ sudo apt install i2c-tools

Type "sudo apt install i2c-tools" and press Enter.

#### File Edit Tabs Help

pi@r	as	bei	rry	pi:•	- \$	suc	do :	i2c	dete	ect	- y	1					
	Θ	1	2	3	4	5	6	7	8	9	a	b	С	d	е	f	
00:																	
10:																	
20:																	
30:																	
40:																	
50:																	
60:																	
70:																	
pi@r	as	ber	rry	<b>pi</b> :•	- \$												

Type "sudo i2cdetect –y 1" and press Enter.

If the secondary device is connected to the I2C bus, the secondary bus address will be displayed.

## CULTIVATION SYSTEM DEVELOPMENT PH.4 COURSE **2. APPENDIX**

Issue Date: First edition published 1<sup>st</sup> November 2021

Author: Dr. KAGA, Yoshitaka

Publishing company: Neo Career Promote CO., LTD.

Address: 5-1-11-202, Okusawa Setagaya-ku TOKYO 158-0083 JAPAN

Home Page: https://www.ncp-8.com/

Contact E-mail: info@ncp-8.com